

REPLACING THE LEG:

Step 1: Turn Rebounder upside down with legs pointing up.



Step 2: Remove the rubber tip from the leg that needs replacing. Set aside.




Step 3: Inside of the leg, you will see a hook where the spring attaches to the leg. Using the Spring Tool, hook the tool to the spring and pull up.



Detach the spring from the leg. Remove the old leg and discard.



Step 4: Slide the new leg on over the spring. Using the spring tool again, hook the spring and pull up to reattach the spring to the new leg.



Step 5: Replace the rubber tip.

